

Hawaiian Ice Machine

Allow ice to soften at least an hour in cooler before using machine.

Lift cover and load ice cubes to about a 1/2 inch from top. Close lid and place cup under chute, turn power button on.

Adjust blade height with black knob to get preferred ice texture.

Machine will not operate with lid open.

To figure ice amount needed:

9 oz cup filled to 12 oz

10 lbs ice = 100 filled cups

20 lbs ice = 200 filled cups

30 lbs ice = 300 filled cups

40 lbs ice = 400 filled cups

50 lbs ice = 500 filled cups

1 gallon of syrup fills 64 cups

1 pump = 1 oz

2 pumps per 12 oz cup

Please Return Machine Clean